

# INSTALLATION GUIDE

## FTC – Field Termination Connector



**1**

Copper Foil Tape  
30mm x 10mm

**2**

Boot  
Cable

**3**

30mm Min.  
10 mm  
S/FTP or U/FTP.F/UTP

**4**

30mm Min.  
10 mm  
Copper Foil Tape

**5**

7/8, 4/5, 3/6, 1/2  
7/8, 4/5, 3/6, 1/2 (Correct)  
7/8, 4/5, 3/6, 1/2 (Incorrect)

**6**

**7**

5~8mm Max.

**8**

Cut 2  
Cut 1  
0.2mm Max.

**9**

Align

**10** Screwing by hand

1 Close  
2 Push  
3 Screw

**11** Optional: using termination helper

3, 1, 2

**12**

NG (Incorrect)  
OK (Correct)

**13**

	Solid	Stranded	Cable (O.D.)
C6A/C7	23~26AWG	23~26AWG	6.0~7.5mm
C8	22~24AWG	22~24AWG	7.0~8.5mm