

INSTALLATION GUIDE

Polarity Change – Uniboot Patchcord GB

<div>1</div> <div></div> <div>Press both sides to unlock the transparent clip</div>	<div>2</div> <div></div> <div>Pull the clip towards connectors end face and remove it completely Attention: do not remove the dust cap unintended</div>
<div>ONLY FOR APC CONNECTORS</div>	
<div>2.1</div> <div></div> <div>Rotate each ferrule 180 degrees so that the grey dots face to the bottom</div>	<div>2.2</div> <div></div> <div>Turn around the complete connector, the red / black indicators are now at the other side (switched) Note: the grey dots are now facing to the top (APC) → continue directly with step 4</div>
<div>ONLY FOR APC CONNECTORS</div>	
<div>3</div> <div></div> <div>Turn around the complete connector The red/black indicators are now at the other side (switched) Note: the grey dots are now facing to the bottom (PC)</div>	<div>4</div> <div></div> <div>Push the clip onto the connector the same way and orientation it was removed Note: to check finally the polarity change red/black indicators have now been changed corresponding to A/B</div>